

DPD TESTER Oxigen O2/pH - Test kit using tablets.

Instructions for use:

1. Rinse the chambers of the tester with the water you will be checking.
2. Fill them up to the line with controlled water (from the pool).
3. Oxygen O2 test - add DPD tablet No.4. Do not touch the tablet with your fingers.
4. pH test - add DPD tablet PHENOL RED. Do not touch the tablet with your fingers.
5. Place the cap on the test chambers and stir repeatedly.
6. After the DPD tablets are completely dissolved, compare the color of the tested water with the scale of O2 and pH values.

Recommended values: O2 - 3.0-8.0 mg/l, pH - 6.9 - 7.4.

Note: Water should be collected 20-30 cm below the surface and 20-30 cm from the edge of the pool.

The Oxygen O2 test determines whether there is a sufficient amount of Oxygen O2 in the pool to destroy bacteria and algae. The pH test determines the pH of the water (acidity, alkalinity).

Important: Perform the tests in the shade and early in the morning or late in the evening, before adding chemicals. Store the tester in a dark and cool place. Keep test chambers clean and dry.